


WELDING TIP



Description :

- Welding a tool onto a weld-on tip modifies the centre distance between the tool centre and the wrench. This modification changes the torque value required. Therefore, a torque controller must be used to recalibrate the torque wrench (E.2000).
- Presentation: black finish.
- Hardness: 46-50 HRc.

References :

	A [MM]	B [MM]	C [MM]	L [MM]	L1 [MM]	[G]
14.14X18	14x18	22	26,3	36,5	24,5	10
14.9X12	9x12	14,7	17,4	24,5	16,5	10