


## 138.S - SPARE STRAP



### Description :

- To be used with the nylon strap wrench.
- 138.S17: spare strap L.430 mm for 138A.17.
- 138.S30: spare strap L.760 mm for 138A.30.
- 138.S48: spare strap L.1200 mm for 138A.48.

### References :

	[G]
138.S17	26
138.S48	44
138.S30	74