


TOOL FOR TRUARC® RINGS



Description :

- For fitting and removing Truarc rings, maximum diameter 6 mm, in difficult access locations.



References :

	L [MM]	[G]
1813	170	19