


TRANSMISSION COLLAR CLAMP



Description :

- To crimp collars on transmission bellows.
- For OETIKER collar.

References :

	H [MM]	WIDTH L [MM]	L [MM]	FOR	[G]
DM.14	20	50	280	245.J2	475